

BRUNO *Out-Sider*® *Micro*



**Bruno Model
ASL-225**

***The Lowest-Cost,
Most-Simplified Outside
Lift On The Market!***



Fits 1-1/4" Hitch Receiver!

OPTIONAL BRUNO POW'R PAC



- ◆ Easy to use!
- ◆ Convenient!
- ◆ Works in most minivans, SUVs, station wagons & sedans!

The complete, independent power supply for your automotive lift!

Pow'rPac easily installs in your vehicle – just plug into the vehicle's power outlet!

- ◆ The **NEW** Bruno Out-Sider® Micro Vehicle Lift, Model ASL-225, is the lightest-weight exterior vehicle lift designed to handle today's popular travel scooters!
- ◆ It's designed with fewer parts than any other outside lift and it's easy to install – it takes less than one hour!
- ◆ Lowest-profile design minimizes rear vision obstruction.
- ◆ Industry-leading 145 lb./65.9 kg. lifting capacity.
- ◆ The Out-Sider® Micro installs on vehicles using a Class I sport or Class II receiver hitch with 12" or less ground-to-receiver clearance.
- ◆ The gas-spring assist provides easy "fold/unfold" of the lift platform. The safety latch prevents unintentional lowering of the lift platform.
- ◆ Convenient control arm lets you operate the lift from a safe distance.
- ◆ Exclusive "lift mast angle adjustment" allows the installer to nest the Out Sider® Micro tight against the rear of the vehicle.
- ◆ An ultra-strength strap system is used to secure the scooter to the platform. It's easy to use and can be operated with one hand!
- ◆ Bruno's R³ Lift Belt/motor combination provides "whisper quiet" operation and maximum reliability and durability.

- ◆ Road and laboratory tested by a certified testing facility.
- ◆ Expert installation and complete after-sale service is provided by Bruno's nationwide network of dealers.
- ◆ Only Bruno has over 25 different interior/exterior scooter, wheelchair and power chair lifts for nearly any sedan, hatchback, station wagon, convertible, minivan, sport utility vehicle (SUV), full-size van, pickup truck and the new cross-over vehicles.
- ◆ Plus, all Bruno Lifts are eligible for reimbursement under the terms of Mobility Programs offered by GM, Saturn, DaimlerChrysler/Dodge, Ford, Toyota, Lexus, Volvo and Volkswagen.



Using the *Bruno Out-Sider® Micro* is easy!



1 Insert key, turn ON and lift tab.



2 Lift lever and fold down platform.



3 Unhook belt and loosen Velcro®.



4 Press switch to lower platform.



5 Place scooter on platform, press switch to raise and secure with belt.

*Velcro® is a registered trademark of Velcro Industries B.V.



6 Lower lever, secure belt to Velcro®, turn key to OFF and remove key.

Represented By:



Bruno Independent Living Aids, Inc., 1780 Executive Drive
P.O. Box 84, Oconomowoc, WI 53066

(262)567-4990 ♦ FAX:(262)953-5501

www.bruno.com